

Tachometers

CT 100 O - CT 100 C



"Select" key

See table
"Functions available from main screen"

"Function" key

- 1x : "Hold" : measure holding
- 2x : "Min/Max" : display of minimum and maximum values from **channel 1** since last request.
- 3x : "Min/Max" : display of minimum and maximum values from **channel 2** since last request.
- 4x : **Back** to held measure.

















"On / off" key

- ON** : Switch-on
- OFF** : Switch-off
- Escape** : Return to previous screen

"Backlight" key


- 1x Level 1
- 2x Level 2
- 3x No backlight


Functions available from main screen

Select probe	1x  →  → Press on  key to scroll down probe types ⇔ Validate with  key
Select unit	2x  →  → Press on  key to scroll down units ⇨ Validate with  key
Automatic shut-off	3x  →  → Press on  key to scroll down minutes ⇨ Validate with  key
Beep	4x  →  → Press on  key to activate or deactivate ⇨ Validate with  key

■ **How to change battery**

1. Remove the front part at the back of the device
2. Remove the old battery
3. Insert the new battery in accordance with proper polarity
drew inside the housing.
4. Replace the front.



 Once returned to KIMO, required waste collection will be assured in the respect of the environment in accordance to 2002/96/CE guidelines relating to WEEE.

www.kimo.fr

EXPORT DEPARTMENT
Boulevard de Beaubourg - Emerainville - BP 48
77312 MARNE LA VALLEE CEDEX 2
Tel : + 33.1.60.06.69.25 - Fax : + 33.1.60.06.69.29

