

Thermometers

TK 100 - TK 150
TK 102 - TK 152



"Select" key

See table
"Functions available from main screen"

"Function" key

- 1x : "Hold" : measure holding
- 1x long : "Auto-Hold" see p.2
- 2x : "Min/Max" : display of minimum and maximum values from **channel 1** since last request.
- 3x : "Min/Max" : display of minimum and maximum values from **channel 2** since last request.
- 4x : Back to held measure.

"On / off" key

- ON : Switch-on
- OFF : Switch-off
- Escape : Return to previous screen

"Backlight" key

- 1x Level 1
- 2x Level 2
- 3x No backlight

"OK" key


- 1x "To validate"
or "Delta temperature" see P2.

Functions available from main screen

	Select probe	1x → → Press to scroll down thermocouple	⇒ Validate with
	Select units	2x → → Press to scroll down units.	⇒ Validate with
	Automatic shut-off	3x → → Press to scroll down minutes.	⇒ Validate with
	Beep	4x → → Press to activate or to deactivate.	⇒ Validate with
[Class 150]	Lower alarm	5x → → Press to select number or sign (Available on channel 1 only)	⇒ Validate with
[Class 150]	Upper alarm	6x → → Press to select number or sign (Available on channel 1 only)	⇒ Validate with
[Class 150]	Auto-hold	1x long press → A beep rings, once measure is stabilized (Available on channel 1 only)	⇒ Exit with
[2 channels]	Delta temperature	1x → Delta temperature value : $T_{\text{channel 2}} - T_{\text{channel 1}}$	⇒ Exit with

■ How to change battery

1. Remove the front part at the back of the instrument
2. Remove old battery
3. Insert the new battery in accordance with proper polarity drew inside the housing.
4. Replace the front.



Once returned to KIMO, required waste collection will be assured in the respect of the environment in accordance to 2002/96/CE guidelines relating to WEEE.

www.kimo.fr

EXPORT DEPARTMENT

Boulevard de Beaubourg - Emerainville - BP 48
77312 MARNE LA VALLEE CEDEX 2

Tel : + 33.1.60.06.69.25 - Fax : + 33.1.60.06.69.29

